
BETRIEBSANLEITUNG
OPERATING INSTRUCTIONS
INSTRUCTIONS DE SERVICE
ISTRUZIONI D'USO
HANDLEIDING
INSTRUCCIONES PARA EL MANEJO
MANUAL DE INSTRUÇÕES
NAUDOJIMOSI INSTRUKCIJA
KASUTUSJUHEND
LIETOŠANAS INSTRUKCIJA
DRIFTSINSTRUKS
DRIFTSINSTRUKTIONER
DRIFTSVEJLEDNING
INSTRUKCJA OBSŁUGI
KEZELÉSI ÚTMUTATÓ
NÁVOD K OBSLUZE
NAVODILO ZA UPORABO
NÁVOD NA OBSLUHU
UPUTE ZA RAD
MANUAL DE OPERATII
TREORACHA OIBRIÚCHÁIN
ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ
EL KITABI
ИНСТРУКЦИИ ЗА ЕКСПЛОАТАЦИЯ
ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ
取扱説明書
사용설명서
使用说明书


KDT 3.60


MAKE IT BECKER.





BECKER



AIR
1



MAX.
PRESSURE
mbar
MAX.
m³/h
DIN EN ISO 11203
Accuracy Class 2
K pA = 3 dB(A)
1m
L pA = 72 dB(A) - 50Hz
L pA = 74 dB(A) - 60Hz
2



71-80 kg
156-176 lbs
3



A > 100mm
A > 4"
> 5°C/41°F
< 45°C/113°F
max. 90%
max.
800m
A
4



No. 2
5 mm
7 mm
10 mm
5



6



MOTOR-PROTECTION
=
SERVICE FACTOR
x
RATED CURRENT
SF 1.XX
50Hz
60Hz
XXX / XXX V
XXX / XXX V
XX / XX A
XX / XX A
7


L2 L1 L3
U1 V1 W1
optional
Bi-metal
PTC
1) motor protection switch
ON (I)
OFF (0)
1
2
MAX 10x/h
>60s
8



9


10


PRESSURE
+p
0
2
10 [m]
1"
1½" + 1x
11



BECKER
year
No
type
frequency
speed
power required
inlet capacity
max. pressure
Hz
min⁻¹
kW
m³/h
mbar
Made in Germany
12

Maintenance






13










14




CLEANING INTERVAL








EN149 - FFP3
42 CFR 84 - N100




15




D1 (Pos. 75)

16





17




D2 (Pos. 104)

18






F1 (standard)	**F1*** (polyester) KDT 3.60/6	**F2** (standard)
No.: 909507	No.: 909587	No.: 909510




Satz / Kit
Pos.: 20, 24, 62, 75, 76, 85, 104, 125, 126, 146, 288

No.: 549000 21100


19




20




21



22





23




KDT 3.60 (standard)	→ No. 90133000004 (SET)
KDT 3.60/0-52	→ No. 90137900004 (SET)
KDT 3.60/6	→ No. 90137900004 (SET)
KDT 3.60/6-29	→ No. 90137900007 (SET)


24



25




26



27


28


29



30



WWW.BECKER-INTERNATIONAL-SHOP.COM

Gebr. Becker GmbH
Hoelker Feld 29-31
42279 WUPPERTAL
GERMANY
info@becker-international.com
www.becker-international.com

BECKER

28100021601 | 2020-03-18 | Alle Rechte vorbehalten

MAKE IT BECKER.

BECKER