







**Betriebsanleitung**  
**Operating Instructions**  
**Instructions de service**  
**Istruzioni d'uso**  
**Handleiding**  
**Instrucciones para el manejo**  
**Manual de instruções**  
**Naudojimosi instrukcija**  
**Kasutusjuhend**  
**Lietošanas instrukcija**  
**Driftsinstruks**  
**Driftsinstruktioner**  
**Käyttöohje**  
**Driftsvejledning**  
**Instrukcja obsługi**



**Kezelési útmutató**  
**Návod k obsluze**  
**Navodilo za uporabo**  
**Návod na obsluhu**  
**Upute za rad**  
**Manual de operatii**  
**Treoracha Oibriúcháin**  
**Οδηγίες χρήσης**  
**Ei Kitabi**  
**Инструкции за експлоатация**  
**Инструкция по эксплуатации**  
**取扱説明書**  
**사용설명서**  
**使用说明书**

**X 4.25 DV**  
**X 4.40 DV**

		<b>MAX. PRESSURE</b> <b>MAX. VACUUM</b>		mbar
				m <sup>3</sup> /h
		<b>X 4.25 DV</b> $L_{pA} = 69/69 \text{ dB(A) [50/60Hz]}$	DIN EN ISO 3744 $K_{pA} = 3 \text{ dB(A)}$	
		<b>X 4.40 DV</b> $L_{pA} = 66/68 \text{ dB(A) [50/60Hz]}$		

<b>1</b> 	$A > 100\text{mm}$ $A > 4"$	$> 5^\circ\text{C}/41^\circ\text{F}$ $< 45^\circ\text{C}/113^\circ\text{F}$	max. 90% max. 800m						
<table border="1"> <tr> <td>X 4.25 DV</td> <td>26 kg</td> <td>57 lbs</td> </tr> <tr> <td>X 4.40 DV</td> <td>38,5 kg</td> <td>85 lbs</td> </tr> </table>	X 4.25 DV	26 kg	57 lbs	X 4.40 DV	38,5 kg	85 lbs	<b>2</b> 		
X 4.25 DV	26 kg	57 lbs							
X 4.40 DV	38,5 kg	85 lbs							





A.

B.

3x A-

2x B- 2Nm

B

A

B

C.





1.

F2


F1

2.





D.

		
		
<b>F1</b> D: 64 mm H: 70 mm No.: 90950501000		<b>F2 (option)</b> D: 64 mm H: 60 mm No.: 909529




**E.**



**F.**

		
<b>7500 h</b>		
	$A_{MIN} > 28mm$ $A_{MIN} < 28mm$	
X 4.25 DV → No. 90139900007 (SET) X 4.40 DV → No. 90139700007 (SET)		

**G.**

**H.**



[www.becker-international.com](http://www.becker-international.com)

**BECKER**

Gebr. Becker GmbH  
 Hölker Feld 29-31  
 D-42279 Wuppertal  
 info@becker-international.com

---

**SERVICE**  
[www.becker-international.com](http://www.becker-international.com)  
 Sales and service network